

## FD SERIES Retail Quick Reference

Sale: Use this function to authorize and capture transactions for settlement. The customer may offer a card for payment in one of three ways:

1) By inserting a "smart card" (one with an embedded chip) into the smart card reader located at the front of the terminal or PIN pad, a technology that adds an extra layer of security. 2) By swiping the card through the magnetic stripe reader; or 3) by tapping a contactless card.

Display	Action
Idle Menu	Touch Sale
Enter Amount \$0.00	Key amount and press [ENTER]
Terminal May Prompt: Enter Tip Amount Or Press Cancel (X) To Skip	Enter tip amount or press Cancel (X) to print a blank tip line.
Terminal May Prompt: Please Enter PIN	Key PIN or press [ENTER] to bypass. (If the issuing bank doesn't allow PIN bypass, the transaction will be canceled and a receipt will print).
Please Present Card	Manually key card number if sale was not initiated by an insert, tap or swipe
Terminal May Prompt: Waiting for PIN Entry	Key PIN and press [ENTER]
Terminal May Prompt: Approved \$\$.\$\$ Collect \$\$.\$\$	Touch desired option. If No is selected, transaction will be voided. Initiate a new transaction to collect full amount.
Accept Partial Amount No Yes	
Host Response	Receipts print

Void: Use this function to delete a transaction that is in the current batch.			
Display			Action
Idle Menu			Touch Other
Reprint	Void	Refund	Touch Void
Enter Transaction SEQ # fro	om Receipt.		Key sequence number and press [ENTER]
Amount	\$0.00		Touch OK
Date	M/DD/YY		
Time	HH:MM		
Approval Code	#####		
Card #			
Token	###########		
Cancel	Ok		
Performing Credit Reversal			
Print Customer Receipt?	No	Yes	Touch desired option

Return/Refund: Use this function to issue a credit to the cardholder's account for goods or services.			
Display			Action
Idle Menu			Touch Other
Reprint	Void	Refund	Touch Refund
Enter Amount \$0.00	)		Enter refund amount and press [ENTER]
Please Present Card	1		Insert, tap, swipe or manually key account number and press [ENTER]
Terminal May Prompt: Waiting for PIN entry			If prompted, have customer enter PIN on PINpad and press [ENTER]
Print Customer Rec	eipt? No	Yes	Touch desired option

Reprint: Use this function to reprint the last transaction or any transaction stored in the terminals memory.			
Display			Action
Idle Menu			Touch Other
Reprint	Void	Refund	Touch Refund
Enter transaction SE	EQ # from receipt		Key sequence number and press [ENTER]
Re-printing receipt			Press Cancel (X) to return to idle prompt

Tip Adjustment: Use this function to add the tip amount to a transaction that is in the current batch.			
Display			Action
Idle Menu			Touch Other
Enter Tips	Reports	Close Batch	Touch Enter Tips
Enter Transaction SEQ a	from Receipt.		Key sequence number and press [ENTER]
Trans SEQ.	#		Touch Edit Tip
Last 4	####		
Trans Amt.	\$1.00		
Tax	\$0.00		
Tip	\$0.00		
Total Amount	\$1.00		
Prev.	Edit Tip	Next	
Enter Tip			Key tip amount and press [ENTER]
Sale Amount	\$1.00		
	\$0.00		
Trans SEQ	#		Press Cancel (X) to return to idle prompt
Last 4	####		
Trans Amt.	\$1.00		
Tax	\$0.00		
Tip	\$0.10		
Total Amount	\$1.10		
Prev.	Edit Tip	Next	

Pre-Auth: Use this function to pre-authorize an amount on a credit card without finalizing the sale immediately. A Pre-Auth must be Voided or Completed prior to end of day settlement of the batch.				
Display			Action	
Idle Menu			Touch Other	
Gift Card	Help	More	Touch More	
Auth			Touch Auth	
Pre-Auth	Complete	Tran Details	Touch Pre-Auth and follow terminal prompts	
Reprint	Void	Print Details		

Pre-Auth Complete: Use the A Pre-Auth must be Voided			ansaction in the terminal batch. of the batch.
Display			Action
Idle Menu			Touch Other
Gift Card	Help	More	Touch More
Auth			Touch Auth
Pre-Auth	Complete	Tran Details	Touch Complete
Reprint	Void	Print Details	
Enter PRE-AUTH SEQ# from Pre-Auth receipt			Key sequence number and press [ENTER]
Amount	\$0.00		Touch Complete
Date Time Approval Code Card # Token Cancel	M/DD/YY HH:MM #### ########## Complete		
Completion Auth amount \$#.## \$0.00			Enter the amount of the sale to be completed and press [ENTER]
Terminal May Prompt: Over/Under authorized Continue? No	Yes		Touch desired option
Print Customer Receipt?	No	Yes	Touch desired option

Reports: Various types of detail and totals reports can be generated for transactions in the current batch (transactions that have not yet been settled)			
Display			Action
Idle Menu			Touch Other
Enter Tips	Reports	Close Batch	Touch Reports
Print Reports	Host Reports		Touch Print Reports
Batch Totals	Card Totals	Tran Details	Touch the desired report to print
Batch History	Server Totals	Server Details	
Pending Pre-Auth	Open Tips		
Printing Report			Press Cancel (X) to return to idle prompt

Settle: Use this function at the end of each day to settle the batch for payment and clear your terminal of transaction information. These procedures are only necessary if Auto Close is disabled.

Display			Action
Idle Menu			Touch Other
Enter Tips	Report	Close Batch	Touch Close Batch
Close Batch?			Touch OK to confirm close
Sales	###	\$#.##	
Refunds	###	\$#.##	
Totals	###	\$#.##	
Tips	###	\$#.##	
Cashback	###	\$#.##	
Cancel		OK	
Dialing			Terminal communicates with the host for approval
Batch Close Complet	е		Press Cancel (X) to return to idle prompt

